




How to Reset the High Limit

When your fryer displays a “Heat Failure” error there are switches located behind the door of the fryer you will want to try resetting. The images below show you where to locate the High Limit Reset Button.

WARNING: *These switches are located near the burners so make sure your fryer has had time to cool before attempting to reset the High Limit or Roll Out switch.*

Reset High Limit

Locate the Reset



Press the Button



1. Open up the fryer door and locate the gas valve.
2. The High Limit Reset Button is located behind the gas valve.
3. Reach your hand on top of the box labeled high limit reset button to feel for the red button.
4. Push the button down and release. You have now reset the High Limit.